


FIT TRACK
1900/3900/5900

hama
THE SMART SOLUTION



1

Removable wristband / Abnehmbares Armband

F Bracelot amovible E Correa de quita y pon NL Afneembare armband I Bracciale rimovibile PL Zdejmowana opaska na rękę H Levehető karpánt
RO Brățară demontabilă CZ Snímatelný pásek na ruku SK Odoberateľný náramok P Bracelete amovível S Avtagbart armband RUS Съемный кистевой
ремешок BG Сменяема каишка GR Αφαιρούμενο λουράκι βραχίονα TR Çıkarılabilir kol bandı FIN Irrotettava rannehihna

2

Sensor button / Sensortaste


F Touche tactile E Tecla de sensor NL Sentoetoets I Pulsante sensore PL Przycisk czujnika H Szenzorgomb RO Tastă senzor CZ Tlačítko senzoru
SK Tlačidlo snímača P Sensor S Sensorknapp RUS Сенсорная кнопка BG Сензорен бутон GR Πλήκτρο αισθητήρα TR Sensör Düğmesi FIN Anturipainike

3

Fastener / Verschluss

F Fermeture E Cierre NL Sluiting I Chiusura PL Zapięcie H Zár RO Dispozitiv de închidere CZ Uzávěr SK Uzáver P Fecho S Lås
RUS Защелка BG Закопчалка GR Κούμπωμα TR Kilit FIN Kiinnitys

Fit Track 1900 / 3900



Fit Track 5900

